MAIN CHARACTERISTICS


The cast iron double sight glass C 164 is intended for the visual control of the flow of the fluids in pipes. Made in cast iron, it is particularly intended for the controls of the flow of the condensate downstream to the steam trap of steam loop. The type to double glass, C164 is double sight glass and is provided with chicanes allowing to create turbulences which improve the visibility of the flow.

AVAILABLE MODELS

DN 15 to DN 200 Connecting with flanges PN 16 raised face.



LIMITS OF USE



REGULATIONS AND STANDARD OF CONSTRUCTION


ITEM	Standard	NB
P.E.D 97/23	DN 15 to 25 : excluded	
P.E.D 97/25	DN 32 to 250 : category II	1115
Materials of cast iron	EN 1503-3	
Flange	EN 1092-2	
Face to Face dimensions	EN 558-1-serial 1	

Modifications reserved

	SECTORIEL S.A. 45 rue du Ruisseau 38290 SAINT QUENTIN-FALLAVIER – FRA NCE	Nbr. pages	1/3
		Ref.	FT2225 ENG
		Rev.	02
		Date	03/14


DIMENSIONS (mm) AND CONNECTIONS

DN	L	F	Drillings Nbr.	Weight (Kg)	
15	130	95	4	2,9	
20	150	105	4	3,5	
25	160	115	4	4	
32	180	140	4	6	
40	200	150	4	6,5	
50	230	165	4	9	
65	290	185	4	15	
80	310	200	8	17,7	
100	350	220	8	24,9	
125	400	250	8		
150	480	285	8	Please consult	
200	600	340	12		



CONSTRUCTION

N°	Item	Qty	Material
1	Body	1	Cast iron EN-GJL-250
2	Glass gasket	4	Fiber
3	Glass	2	Soda lime
4	Cover	2	Cast iron EN-GJL-250
5	Screw	*	Steel 8.8
6	Nut	*	Steel 8.8



* Following DN

INSTALLATION

The controller can be installed in any position. For steam trap working by discharge, please respect a lenght of 1 meter between the trap and the sight glass to avoid a thermal shocks on the glass.

MOUNTING

- 1 Verify the adequacy of the device to its use.
- 2 Choose flanges gaskets adapted to the conditions of use.
- 3 Present the sight glass between the flanges of the piping so that the glasses are visible for the operators.
- 4 Insert the flanges gaskets.
- 5 Insert screws into the holes of flanges and tighten the nuts.
- 6 Put into service.

Modifications reserved

	SECTORIEL S.A.	Nbr. pages	2/3
	45 rue du Ruisseau 38290 SAINT QUENTIN-FALLAVIER – FRA NCE	Ref.	FT2225 ENG
		Rev.	02
		Date	03/14

MAINTENANCE

- 1 Before any intervention, shut off the pipe upstream and downstream.
- 2 Depressurize and drain the pipe.
- 3 Wait for its complete cooling at room temperature.
- 4 Carry the necessary safety equipments for this type of intervention (gloves and glasses).
- 5 Put down the cover and remove the glass.
- 6 Clean the internal parts.
- 7 Verify the state of the glass, detect any starting of corrosion or possible erosion and change it necessary.
- 8 Put back the installation in service.

SPARE PARTS

Kit C164 (1 Glace – 2 Joints)				
DN	ø	Thickness (mm)	Code	
15	59,8	9,8		
20	59,8	9,8	981018	
25	59,8	9,8		
32	65,4	11,9	981019	
40	65,4	11,9	981019	
50	80	14,8	981020	
65	109,5	18,7	001021	
80	109,5	18,7	981021	
100	136	23	981022	

Modifications reserved

	SECTORIEL S.A. 45 rue du Ruisseau 38290 SAINT QUENTIN-FALLAVIER – FRA NCE	Nbr. pages	3/3
		Ref.	FT2225 ENG
		Rev.	02
		Date	03/14